



## Storm Window Installation Instructions

**It is important that a Falcon Storm Window be installed square and plumb to insure correct and proper operation.**

1. Center the storm window over the opening.
2. Install installation screws in the head rail of the storm window.
3. Measure the window diagonally from upper left corner to lower right corner and upper right corner to lower left corner to insure the storm window is square. If the diagonal measurements are not equal, adjust the storm window until these measurements are equal.
4. With the storm window square, install one installation screw on each side in the lowermost installation hole.
5. Measure across the top and center of the storm window. If needed, adjust the storm window until both measurements are equal. *Note: This step may be skipped if storm window has a stabilizer bar.*
6. With both top and center measurements equal, install one installation screw in the center installation hole on each side of the storm window.
7. Complete installation by applying all remaining installation screws.

**CAUTION:** Excessive pressure on the outside window frame may cause flanges to spread further than designed. This could cause inserts to become loose or even fall out.